

# Aesculap Schermaschinen

spare part list: GT6xx Bonum



GT640220 spur gear



GT647 cutter head packed cattle  
GT657 cutter head packed horse



GT367201 rocker



GT367202 vibratory spring



GT640215 PT-screw 30x14



GT640225 regulating screw

# Aesculap Schermaschinen

## spare part list: GT6xx Bonum



**GT367207 cylinder screw**




**GT367802 spacer piece left**



**GT367803 spacer piece right**



**GT610405 nut**



**GT610304 rocker**



**GT610307 spring link**

# Aesculap Schermaschinen

## spare part list: GT6xx Bonum



TA008295 screw shaft



TA010017 screw M4x16



TA015497 screw M5x12



GT641 Li-Io-batterie



GT643 ( -G / -K / -A ) charging station

# Aesculap Schermaschinen


spare part list: GT6xx Bonum



TA015304 instruction for use



TA015349 case sticker cattle



TA015350 case sticker horse



TA015351 case sticker horse




GT640819 hard case

# Aesculap Schermaschinen

spare part list: GT6xx Bonum




GT640895 engine packed



GT640896 PCB packed



GT640801 lower case



GT640802-RO upper case




GT640802-BL upper case



GT640248 button holder

# Aesculap Schermaschinen

## spare part list: GT6xx Bonum



GT640249 switch



GT604 oil packed



TA009222 screwdriver

Version von 2018/06/05